
Ness Sensitive 1.2 mA trigger 924 APPLICATIONS AND WIRING DIAGRAMS



The "-" Access Output is connected to -T on the Ness-924.

jumper between POS and +T (for positive output controls) or between NEG and -T (for negative output controls).